

NAPCO K1CA & K2 KEYPAD QUICKGUIDE



Napco K1CA



Napco K2

Arm System – All protected windows and doors must be closed. Ready light should be green.

- **Away**—Press Code then **AWAY** Key
Arms all devices including motion detectors.
- **Stay**— Press Code then **STAY** Key. “Bypass” will appear in top left corner of keypad
Arms all devices and automatically bypass all motion detectors.
- **Instant**—Press Code then **STAY** key. Then Press & Hold Stay Key for 2 Secs
Arms entry doors without delay and bypass all motion detectors.
- **Easy Arm Away**-Press and hold **AWAY** key until second beep sounds
- **Easy Arm Stay**-Press and hold **STAY** key until second beep sounds.

Disarm System/Silence an Alarm: Enter code then **ENTER** key

Reset System (Use after silencing and noting activated zones): Press **RESET** key

Chime On/Off: Press MENU button until “Activate/Deactive Chime” appears. Press **STAY/YES** key


Bypass A Zone: Press **BYPASS** key. Then press two digit zone number to bypass.
(ex: 4=04) If successful “bypass” will appear in top left corner of keypad screen.

Panic Buttons: Press and hold the following combination for 3 seconds

POLICE	FIRE DEPT.	AMBULANCE/EMS
9P & *	7F & *	8A & *

Change or Add Additional Codes: Enter Code then Press Menu Key until “Activate Program”. Press **STAY/YES** key. Enter Digits of User code to be programmed (ex: 4=04) (more than 1 code in system). Press **MENU** key twice. Enter new user code (up to 6 digits). Press **ENTER** to save code.

IF MONITORED CUSTOMER: Send code change to codechange@ialarmnj.com. We can connect and handle code changes for you at no charge.

Delete A User Code: Enter Code then Press Menu Key until “Activate Program”. Press **STAY/YES** key. Enter digits of code user number (ex: 4=04) to be programmed. **MENU** key twice. Press , 0 to erase each digit of the user code. Press **ENTER** at end to save changes.

Sending a Test Signal: Press **FUNCTION** key until display reads “Activate Dialer Test”. Press **STAY/YES** key.